

BOSCH MSZV0FB3-17004303 Vacuum food bag with zipper



SKU: IT49796

€19.90

Specifications

Excellent results

- A special bag that closes airtight and keeps food fresh in storage, freezing or out of the refrigerator.
- The air is easily removed to store food in empty air.
- Sous-vide: Cook your meat or fish in a vacuum, as well as you want, at a temperature of up to 85. C.

Comfort / Cleaning

- Food bags are reusable, washable and easily sealed with a double zipper.
- Wash in the dishwasher.
- Designed for the innovative Bosch ErgoMixx Fresh blender rod and VitaMaxx vacuum blender.

- In the white part of the bag you can note its contents and storage date.

Material and safety

- All plastics that come in contact with food are Bisphenol A (BPA free)
- Food bags are airtight, do not retain odors from food, are washable and are compatible with microwave ovens.