

# RYOBI RC18120-150X Battery 5.0Ah Set with 18V Charger



SKU: IT67320

**€139.95**

## Specifications

---

### Technical Specifications

- Battery voltage: 18V
- Battery capacity: 5.0 Ah
- Charging time: 150 min

### CAUTION!

- Change the battery cartridge before completely discharged. Always stop tool operation and charge the battery cartridge when you notice less tool power
- Never recharge a fully charged battery cartridge. Overcharging shortens the battery service life
- Charge the battery cartridge with room temperature at 10°C-40°C (50°F-104°F). Let a hot battery cartridge cool down before charging it

- Charge the battery cartridge if you do not use it for a long period (more than 6 months)

### **General Specifications**

- Compatible with all Ryobi ONE+ 18V tools
- Drive up to 1150 screws with Drill
- Cuts up to 100 meters of 13mm plywood with Circular Saw
- Run time may vary by tool, battery and application
- IntelliCell™ technology monitors and balances individual cells to maximize runtime